

ReadyLift® (Part# 66-7822A) Instructions
Torsion Bar Unloading Tool



GREASE BEFORE USE. Completely remove the threaded bolt and thoroughly grease the inside threads of the tool with high quality Black or Red Molybdenum. Repeat as needed, or after use on four vehicles (eight torsion keys). Remove all metal shavings from the tool threads before re-greasing.